



LINEA BRACCIOLI BRPANDA18

**PANDA
DAL
10/2018**

VISTA LATERALE



VISTA BRACCIOLO



VISTA DALL'ALTO



VISTA FRONTALE



VISTA DAL RETRO



LEVA LARGA NON OK



LEVA LUNGA OK



INSTALLATO LATERALE



ISTRUZIONI PER L'INSTALLAZIONE

FIAT PANDA 2018 – Tunnel centrale basso

Bracciolo

istruzioni di montaggio

-Posizionare la staffa del bracciolo sul tunnel centrale (vedere disegno)

-Avvitare le viti fornite con un cacciavite

-Coprire le teste delle viti con i tappini in plastica in dotazione

Per regolare la posizione del cuscino: svitare leggermente le 2 viti presenti sotto la staffa, avanzare o arretrare nella posizione desiderata, stringere le viti

FIAT PANDA 2018 – Low central tunnel

Armrest

fitting instructions

-Position the bracket of the armrest on the central tunnel as shown in the drawing.

-Secure the screws with an hand screwdriver

-Cover the head of the screws with the supplied plastic stoppers

stoppers

ADJUST THE PAD POSITION: unscrew the 2 screws under the bracket, adjust the horizontal position of the pad, tighten the two screws



Made in Italy